

---

## Installation Instructions – Aspherical Mirror Set

**All VW/Audi models**



## Overview

- Vehicles sold outside of the North American Region (NAR) are equipped with very different outside rear view mirrors than NAR products. The Rest of World (ROW) mirrors have an aspherical section on the driver side mirror. This provides the driver with a much wider view of what is behind the vehicle. The transition from planar glass to the convex (aspherical) section is marked with a dotted line. The outer 35% of the mirror area is aspherical.
- The ROW passenger side mirror has a slightly smaller radius of curvature than US legislation specifies for the NAR mirror, thus providing a greater field of view. It also does not have a 'Objects in the mirror are closer than they appear' message stenciled on it, because no government in the ROW marketing region has thought it necessary to legislate that this warning appear on the rear view mirror.

## Difficulty Rating



## Parts Required for Installation

- [Aspherical Mirror set](#)

## Tools Required for Installation

- Fingers/hands

## Installation

- Adjust the mirror so its pointing fully inward



- Put your fingers behind the mirror, and gently pry it out
- **\*\*make sure everything is warm (room temperature) before you do this.\*\***



## Cupra R Spoiler

---

- Be Aware there is limited room for movement with all the wires connected
- One set of wires is for the heater, the other is for the anti-dazzle dimming,
- Note: some cars do not have anti-dazzle dimming so you won't have to worry about these wires.



- Take careful note of how the connectors is attached to the mirror, and how the wires are routed on the back face of the mirror.



- Now unplug the wires from old mirror, you then can remove the old mirror and can now attach the wires to the aspherical mirrors, then repeat steps in reverse.